



FOIL - SCREWS, WHERE TO USE THEM...

Last update: 30/01/2020

EAN Code	Ref	Item	Applications					
3664984032081	77207-8002	T-Nuts (A4) x4	Fasten the Mast Top Plate on the board with deep (US) tracks (x4)	Fasten the Mast Top Plate on the boards with shallow tracks (x4)				
3664984032098	77207-8004	M6-12mm tapered head screws (A4 - T30 torx) x4	no more used at the moment					
3664984032104	77207-8005	M6-15mm tapered head screws (A4 - T30 torx) x4	Fasten all stabilizers onto the fuselage (all foils) (x2)	Fasten the Mast Top Plate on the boards with shallow tracks (x4)	Fasten the IC6 950 wing on the Alu Fuselage 70 (x2)	Fasten the Mast Top Plate on the boards with M6 inserts (Papenoo, Papenoo Conv, SW2...)		
3664984032111	77207-8006	M6-16mm tapered head screws (A4 - T30 torx) x2	no more used at the moment (can be used to fasten stabs on fuselages)					
3664984032128	77207-8007	M6-25mm tapered head screws (A4 - T30 torx) x4	Fasten the Mast Top Plate on the Alu Mast (x2)	Fasten the Mast Top Plate on the boards with deep (US) tracks (x4)	Fasten the IC6 950 wing on the Alu Fuselage 70 (x2)	Fasten the Titan Mast Foot on the Alu Mast (x2)	Fasten the Carbon Ft Wing on the Fuselage Carbon (x2) > Mirage Carbon - Phantom Carbon - Gravity Carbon - Levo Carbon	
3664984032135	77207-8008	M6-30mm tapered head screws (A4 - T30 torx) x4	Fasten the Escape 530 Plane on the Carbon Mast or Titan Mast Foot (x3)					
3664984032142	77207-8009	M6-32mm tapered head screws (A4 - T30 torx) x4	Fasten the Mirage Carbon wings on the Carbon Mast or Titan Mast Foot (x3)	Fasten the Phantom Carbon wings on the Carbon Mast or Titan Mast Foot (x3)	Fasten the Gravity Carbon wings on the Carbon Mast or Titan Mast Foot (x3)			
3664984032159	77207-8010	M6-38mm tapered head screws (A4 - T30 torx) x4	Fasten the Levo Carbon wings on the Carbon Mast or Titan Mast Foot (x3)					
3664984032166	77207-8011	M6-50mm cylindrical head screws (A4 - T30 torx) x2	Fasten the Mast Top Tuttle on the Alu Mast (x2)	Fasten the Mast Top KF on the Alu Mast (x2)	Fasten the Mast Top DKF on the Alu Mast (x2)			
-	-	M6-80mm hexagonal head screws (A4) x2	Fasten the Top Tuttle on the Rocket Air Boards (front)					
-	-	M6-100mm hexagonal head screws (A4) x2	Fasten the Top Tuttle on the Rocket Air Boards (back)					